

# FOLDER E PROSPECTO

CLICAR NO LINK DO MODELO

## MEMÓRIA DESKTOP DDR2

2GB DDR2 667MHZ DESKTOP → [KVR667D2N5/2G](#)

2GB DDR2 800MHZ DESKTOP → [KVR800D2N6/2G](#)

## MEMÓRIA DESKTOP DDR3

2GB DDR3 1333MHZ DESKTOP → [KVR13N9S6/2](#)

2GB DDR3 1600MHZ DESKTOP → [KVR16N11S6/2](#)

4GB DDR3 1333MHZ DESKTOP → [KVR1333D3N9/4G](#)

4GB DDR3 1600MHZ DESKTOP → [KVR16N11S8/4](#)

4GB DDR3 1866MHZ DESKTOP → [HX318C10F/4](#)

8GB DDR3 1333MHZ DESKTOP → [KVR1333D3N9/8G](#)

8GB DDR3 1600MHZ DESKTOP → [KVR16N11/8](#)

8GB DDR3 1600MHZ DESKTOP → [HX318C10FB/8](#)

## MEMÓRIA DESKTOP DDR4

4GB DDR4 2133MHZ DESKTOP → [KVR21N15S8/4](#)

4GB DDR4 2400MHZ DESKTOP → [KVR24N17S6/4](#)

4GB DDR4 2666MHZ DESKTOP → [KVR26N19S6/4](#)

---

8GB DDR4 2133MHZ DESKTOP → [HX421C14FB2/8](#)

8GB DDR4 2400MHZ DESKTOP → [KVR24N17S8/8](#)

8GB DDR4 2666MHZ DESKTOP → [KVR26N19S6/8](#)

8GB DDR4 3200MHZ DESKTOP → [KVR32N22S8/8](#)

---

16GB DDR4 2133MHZ DESKTOP → [HX421C14FB2K2/16](#)

16GB DDR4 2400MHZ DESKTOP → [KVR24N17D8/16](#)

16GB DDR4 2666MHZ DESKTOP → [KVR26N19S8/16](#)

16GB DDR4 3200MHZ DESKTOP → [HX432C16FB3/16](#)

---

## MEMÓRIA NOTEBOOK DDR2

2GB DDR2 667MHZ NOTEBOOK → [KVR667D2S5/2G](#)

2GB DDR2 800MHZ NOTEBOOK → [KVR800D2S6/2G](#)

## **MEMÓRIA NOTEBOOK DDR3**

**2GB DDR3 1333MHZ NOTEBOOK → [KVR1333D3S9/2G](#)**

**2GB DDR3 1600MHZ NOTEBOOK → [KVR16LS11S6/2](#)**

**4GB DDR3 1333MHZ NOTEBOOK → [KVR13S9S8/4](#)**

**4GB DDR3 1600MHZ NOTEBOOK → [KVR16LS11/4](#)**

**4GB DDR3 1866MHZ NOTEBOOK → [HX318LS11IB/4](#)**